

P525/3  
Chemistry  
Paper 3  
July - August 2019  
3 ¼ hours



UGANDA MUSLIM TEACHERS' ASSOCIATION

Name ..... UMTA JOINT MOCK EXAMINATIONS 2019  
*MARKING GUIDE*

Centre/Index No. .... Signature .....

UGANDA ADVANCED CERTIFICATE OF EDUCATION

Chemistry  
Paper 3  
3 hours 15 Minutes

**INSTRUCTIONS TO CANDIDATES:**

- This paper consists of three compulsory questions.
- All questions must be answered in the spaces provided.
- Mathematical tables (3 – figure tables) and silent non-programmable scientific electronic calculators may be used.
- Candidates are advised to read through the paper and cross check with the apparatus and chemicals provided in the first fifteen minutes.

For Examiners' use only			
Q. 1	Q. 2	Q. 3	Total
29	34	17	80

You are provided with the following;

**FA1** which is a solution containing  $3.16 \text{ g l}^{-1}$  of potassium manganite (VII).

**FA2**, which is a solution of ammonium iron (II) sulphate – 6 – water.


Solid T, which is impure potassium chlorate (V) ( $\text{KClO}_3$ )  
2M sulphuric acid

**You are required to;**

- Standardize solution **FA2** using **FA1**
- Determine the percentage purity of solid T.

### Theory

In acidic medium, chlorate (V) ions react with iron (II) ions according to the following equation.



### Procedure A:

a) Pipette  $10 \text{ cm}^3$  of **FA2** into a clean conical flask followed by an equal volume of 2M sulphuric acid and then titrate the mixture with **FA1** from the burette until the end point. Repeat the titration until you obtain consistent readings. Enter your results in the table I below.

**Table I**

Volume of pipette used = 10.0  $\text{cm}^3$  (½ marks)

Experiment	I	II	III
Final burette reading / $\text{cm}^3$	<u>10.00</u>	<u>24.90</u>	<u>29.90</u>
Initial burette reading / $\text{cm}^3$	<u>0.00</u>	<u>15.00</u>	<u>20.00</u>
Volume of FA I used / $\text{cm}^3$	<u>10.00</u>	<u>9.90</u>	<u>9.90</u>

(4½ marks)

Titre values used to calculate average volume of **FA1**

9.90 and 9.90

(½ marks)

Therefore Average volume of **FA1** =  $\frac{9.90 + 9.90}{2} = 9.90 \text{ cm}^3$

(2½ marks)

- $\pm 0.1$  ✓✓✓
- $\pm 0.2$  ✓✓
- $\pm 0.3$  ✓✓
- $\pm 0.4$  ✓
- $\pm 0.5$  ✓

### Questions



Calculate the molar concentration of in FA2.

(K = 39, O = 16, Mn = 55)

(4 ½ marks)

$$\text{R.F.M of } \text{KMnO}_4 = (39 \times 1) + (55 \times 1) + (16 \times 4) = 158$$

158g of  $\text{KMnO}_4$  contains 1 mole

$$3.16\text{g of } \text{KMnO}_4 \text{ contains } \left( \frac{3.16}{158} \right) \text{ moles} = 0.02 \text{ moles}$$

1000cm<sup>3</sup> of FA<sub>1</sub> contains 0.02 mole of  $\text{MnO}_4^-$

$$9.9\text{ cm}^3 \text{ of FA}_1 \text{ contain } (0.02 \times 9.9) \text{ moles of } \text{MnO}_4^-$$

mole ratio of  $\text{MnO}_4^- : \text{Fe}^{2+}$  is 1:5

$$\text{moles of } \text{Fe}^{2+} \text{ that reacted} = \left( \frac{5 \times 0.02 \times 9.9}{1000} \right) \text{ moles}$$

$$1000\text{ cm}^3 \text{ of FA}_2 \text{ contains } \left( \frac{5 \times 0.02 \times 9.9}{1000} \right) \text{ moles}$$

$$1000\text{ cm}^3 \text{ of FA}_2 \text{ contains } \left( \frac{5 \times 0.02 \times 9.9 \times 1000}{1000 \times 10} \right) \text{ moles of } \text{Fe}^{2+} = 0.099\text{M}$$

Procedure B

b) Weigh accurately 0.5g of T and add about 100cm<sup>3</sup> of water in a beaker. Stir to dissolve and transfer the contents of the beaker into a 250cm<sup>3</sup> volumetric flask. Make up to the mark with distilled water. Label the resultant solution FA3.

c) Pipette 10cm<sup>3</sup> of FA3 into a conical flask. Add 35cm<sup>3</sup> of FA2 using a measuring cylinder followed by an equal volume of 2M sulphuric acid. Heat the mixture to about 85°C and then cool in cold water for 3 minutes. Titrate the cold mixture with solution FA1 from the burette until the end point. Repeat the titration until you obtain consistent readings. Enter your results in table II below.

Table II

Mass of empty bottle + T	=	40.50	g	1 dp or 2 dp
Mass of empty bottle alone	=	40.00	g	
Mass of T alone	=	0.50	g	
Volume of pipette used	=	10.0	cm <sup>3</sup>	(2marks)

06

Experiment	I	II	III
Final burette reading /cm <sup>3</sup>	25.20	25.20	30.20
Initial burette reading /cm <sup>3</sup>	0.00	10.00	5.00
Volume of FA 1 used /cm <sup>3</sup>	25.20	25.20	25.20

Titre values used to calculate average volume of FA1 used are

25.20 and 25.20 cm<sup>3</sup> (½ marks)

Therefore average volume of FA1 used =  $\frac{25.20 + 25.20}{2}$  cm<sup>3</sup>

Questions

d) Calculate the number of moles of;

i) Excess iron (II) ions in FA2 that reacted with manganate (VII) ions.

1000cm<sup>3</sup> of FA1 contains 0.02 moles of MnO<sub>4</sub><sup>-</sup> (2 ½ marks)

25.20cm<sup>3</sup> of FA1 contains  $(0.02 \times \frac{25.20}{1000})$  moles of MnO<sub>4</sub><sup>-</sup>

mole ratio of MnO<sub>4</sub><sup>-</sup> : Fe<sup>2+</sup> is 1:5

moles of excess Fe<sup>2+</sup> that reacted =  $(5 \times 0.02 \times \frac{25.2}{1000})$  mole

= 2.52 × 10<sup>-3</sup> moles

ii) Iron (II) ions that reacted with 10cm<sup>3</sup> of chlorate (V) ions in FA3.

1000cm<sup>3</sup> of FA2 contains 0.099 moles of Fe<sup>2+</sup> (1½ marks)

35cm<sup>3</sup> of FA2 contains  $(0.099 \times \frac{35}{1000})$  moles of Fe<sup>2+</sup>

= 3.465 × 10<sup>-3</sup> moles

Moles of Fe<sup>2+</sup> that reacted with ClO<sub>3</sub><sup>-</sup> = 3.465 × 10<sup>-3</sup> - 2.52 × 10<sup>-3</sup>

= 9.45 × 10<sup>-4</sup> moles



e) Determine the percentage purity of T

(K = 39, Cl = 35.5, O = 16)

(2 ½ marks)

Mole ratio of  $\text{ClO}_3^- : \text{Fe}^{2+}$  is 1:6 ✓

$$\text{moles of } \text{ClO}_3^- \text{ in T} = \left(\frac{1}{6} \times 9.45 \times 10^{-4}\right) \text{ moles}$$
$$= 1.575 \times 10^{-4} \text{ moles}$$

$$\text{Rfm of } \text{KClO}_3 = (39 \times 1) + (35.5 \times 1) + (16 \times 3) = 122.5 \text{ ✓}$$

1 mole of  $\text{KClO}_3$  weighs 122.5g

$$1.575 \times 10^{-4} \text{ moles of } \text{KClO}_3 \text{ weighs } (122.5 \times 1.575 \times 10^{-4}) \text{ g ✓}$$
$$= 0.0193 \text{ g}$$

10 cm<sup>3</sup> of  $\text{FA}_3$  contains 0.0193 g of  $\text{KClO}_3$  ✓

$$250 \text{ cm}^3 \text{ of } \text{FA}_3 \text{ contains } \left(0.0193 \times \frac{250}{10}\right) \text{ g of } \text{KClO}_3 \text{ ✓}$$
$$= 0.4825 \text{ g ✓}$$

$$\text{Percentage purity of T} = \frac{0.4825}{0.5} \times 100\% \text{ ✓}$$
$$= 96.5\% \text{ ✓}$$

Alternatively

alternatively

$$10 \text{ cm}^3 \text{ of } \text{FA}_3 \text{ contains } 1.575 \times 10^{-4} \text{ moles of } \text{ClO}_3^-$$
$$250 \text{ cm}^3 \text{ of } \text{FA}_3 \text{ contains } \left(1.575 \times 10^{-4} \times \frac{250}{10}\right) \text{ moles of } \text{ClO}_3^-$$
$$= 3.9375 \times 10^{-3} \text{ moles}$$

1 mole of  $\text{KClO}_3$  weighs 122.5g

$$3.9375 \times 10^{-3} \text{ moles of } \text{KClO}_3 \text{ weighs } (122.5 \times 3.9375 \times 10^{-3}) \text{ g ✓}$$
$$= 0.482 \text{ g ✓}$$

$$\text{Percentage purity of T} = \frac{0.482}{0.5} \times 100\% \text{ ✓}$$
$$= 96.5\% \text{ ✓}$$



2. You are provided with substance Y which contains three cations and one anion. You are required to carry out the following tests on Y to identify the cations and anion in it. Identify any gases evolved. Record your observations and deductions in the table below.

Tests	Observations	Deductions
a) Heat a spatula end-ful of Y in a dry test tube until there is no further change.	<ul style="list-style-type: none"> <li>- Y is a white crystalline solid</li> <li>- yellow / brown residue</li> <li>- colourless gas turn moist blue litmus paper red and acidified <math>K_2Cr_2O_7</math> from orange to green</li> <li>- Colourless gas with choking smell turns moist red litmus blue and dense white fumes with HCl</li> <li>- colourless liquid turns anhydrous copper(II) sulphate from white to blue</li> <li>- white sublimate</li> </ul>	Non-transition metal ions $Fe^{3+}$ $SO_2$ , $SO_4^{2-}$ or $SO_3^{2-}$ present $NH_3$ hence $NH_4^+$ present water of crystallisation (Hydrated salt) Ammonium salt.
b) Shake two spatula end-ful of Y in a boiling tube with about $3cm^3$ of water. Add dilute sodium hydroxide solution to the mixture dropwise until in excess. Warm and filter keep both the filtrate and the residue.	<ul style="list-style-type: none"> <li>- Brown / yellow solution</li> <li>- Brown ppt insoluble in excess</li> <li>- Brown residue</li> <li>- Colourless filtrate</li> <li>- colourless gas with choking smell turn moist litmus from red to blue and dense fumes with HCl</li> </ul>	$Fe^{3+}$ $Fe^{3+}$ $Fe^{3+}$ $Zn^{2+}$ , $Pb^{2+}$ or $Al^{3+}$ $NH_3$ hence $NH_4^+$ confirmed
c) To the filtrate, add dilute nitric acid dropwise until the solution is just acidic. Divide the acidic solution into six parts.	<ul style="list-style-type: none"> <li>- White ppt soluble in the acid</li> </ul>	$Zn^{2+}$ , $Pb^{2+}$ or $Al^{3+}$
i) To the first part of the acidic solution, add dilute sodium hydroxide solution dropwise until in excess.	<ul style="list-style-type: none"> <li>- white ppt soluble in excess</li> </ul>	$Zn^{2+}$ , $Pb^{2+}$ or $Al^{3+}$
ii) To the second part of the acidic solution, add dilute ammonia solution drop-wise until in excess.	<ul style="list-style-type: none"> <li>- White ppt insoluble in excess</li> </ul>	$Al^{3+}$ or $Pb^{2+}$
iii) To the third part of the acidic solution, add 2-3 drops of potassium iodide solution.	<ul style="list-style-type: none"> <li>- No observable change</li> </ul>	$Pb^{2+}$ absent so $Al^{3+}$ present



iv) To the fourth part of the acidic solution, add 2-3 drops of litmus solution followed by ammonia solution drop-wise until in excess.	Blue-lake solution	$Al^{3+}$ confirmed	1½
v) To the fifth part of the acidic solution, add 2-3 drops of lead (II) nitrate solution and heat.	White ppt insoluble on heating	$SO_4^{2-}$	1½
vi) Use the sixth part to carry out a test of your own choice to confirm the anion in Y. Barium nitrate solution is added	White ppt	$SO_4^{2-}$ confirmed	2
d) Wash the residue with water and dissolve it in dilute hydrochloric acid and divide the solution into three parts.	Brown/yellow solution	$Fe^{3+}$	1
i) To the first part of the acidic solution, add dilute sodium hydroxide solution drop-wise until in excess.	Brown ppt insoluble in excess	$Fe^{3+}$	0½
ii) To the second part of the acidic solution, add dilute ammonia solution dropwise until in excess.	Brown ppt insoluble in excess	$Fe^{3+}$	1½
iii) To the third part of the acidic solution add 3-4 drops of potassium thiocyanate solution.	Blood-red solution	$Fe^{3+}$ confirmed	1½

The cations in Y are  $NH_4^+$ ,  $Al^{3+}$  and  $Fe^{3+}$

The anion in Y is  $SO_4^{2-}$



3. You are provided with an organic compound N. You are required to identify the nature of compound N. Carry out the following tests on the compound and record your observations and deductions in the table below.

Tests	Observations	Deductions
a) Burn a spatula end-ful of Q on a porcelain dish or at the end of a spatula.	Q burn with a blue/yellow non-sooty flame	<del>saturated aliphatic organic compound</del> of low carbon content. (02½)
b) Shake 1cm <sup>3</sup> of Q with about 2cm <sup>3</sup> of water and test with litmus.	Q is miscible/soluble in water forming colorless solution. solution turns blue litmus red	- polar organic compound of low molecular mass - Acidic compound probably carboxylic acid (03)
c) To 0.5cm <sup>3</sup> of Q add 2-3 drops of sodium carbonate solution.	No effervescence occurred	Carboxylic acid confirmed absent (02)
d) To 0.5cm <sup>3</sup> of Q, add 2-3 drops of acidified potassium dichromate solution and heat.	orange solution turns to green	Reducing agent probably primary alcohol, secondary alcohol or aldehyde. (02)
e) To 0.5cm <sup>3</sup> of Q, add 2-3 drops of Brady's reagent.	yellow ppt	Aldehyde present. (01)
f) To about 1cm <sup>3</sup> of Q, add acidified potassium dichromate solution and heat. Then add ethanol followed by 4-5 drops of concentrated sulphuric acid. pour the mixture into a small beaker of cold water	- orange solution turn to green. - sweet fruity smell	- Aldehyde oxidised (Reducing agent) - Ester formed So Aldehyde oxidised to carboxylic acid (02½)
g) To about 0.5cm <sup>3</sup> of Q, add about 4cm <sup>3</sup> of iodine solution followed by sodium hydroxide solution drop-wise until the brown colour of iodine is just discharged.	yellow ppt	Q is Ethanal (Q is of the form $\text{CH}_3\text{C}(=\text{O})\text{H}$ ) (01)
h) To about 1cm <sup>3</sup> of Q, add about 5 drops of tollen reagent and heat gently.	silver mirror was formed	Q is ethanal (aldehyde confirmed) (02)

Comment on the nature of Q.

Q is Ethanal (01)

alternatively / Saturated aliphatic aldehyde of the form  $\text{CH}_3\text{C}(=\text{O})\text{H}$

END

17